

# Assembly Instructions

## Arc Floor Lamp

- Before you begin to assemble your new floor lamp, please check to ensure that all parts have been supplied.
- Follow instructions closely as deviation from them may void your warranty and present a possible safety risk.
- It is recommended that assembly is done on a soft surface like carpet to avoid any damage.
- If you experience any problems with your new purchase please phone Freedom Customer Service (FCS) on 1300 135 588 (Customers outside Australia should contact their closest Freedom store.)

### Care Information:

Periodically check and re-tighten all fasteners.

Wipe down surfaces using a clean cloth weekly.

Ensure that the switch is in the off position and the plug is removed from the wall socket when changing light globes

Light globes may get extremely hot when in use. Only remove light globes after allowing the globe to cool.


This floor lamp is not intended for use by children without supervision.

This floor lamp is not designed for outdoor use.

### Hardware



Wrench x 1



### Caution

Ensure the power is switched off at the wall socket and DO NOT connect at this stage.

- Step 1. Insert pole 'A' into base plate 'E'. Tighten the post using the nut 'F' and the wrench provided.
- Step 2. Attach support arm 'D' to support arm 'C'.
- Step 3. Attach arm D-C to pole 'B'.
- Step 4. Attach D-C-B to pole 'A'.
- Step 5. Attach shade by screwing cap 'G' into lamp fitting