

Assembly Instructions

Vika Outdoor Table

- Before you begin to assemble your new piece of furniture, please check to ensure that all parts have been supplied.
- Follow instructions closely as deviation from them may void your warranty and present a possible safety risk.
- It is recommended that assembly is done on a soft surface like carpet to avoid any damage.
- If you experience any problems with your new purchase please phone our Customer Service Hotline 1800 807 416 (Customers outside Australia should contact their closest Freedom store.)

Care Information:

Periodically check and re-tighten all fasteners. Apply Freedom Outdoor Timber Oil twice a year, closely following the instructions on the can.

Hardware



8 x Part A
Washer



8 x Part B
Nut



1 x Part C
Wrench

Step 1.

